Evaluates: MAX20077/MAX25277

General Description

The MAX20077 evaluation kit (EV kit) provides a proven design to evaluate the MAX20077/MAX25277 2.1MHz/400kHz high-voltage mini-buck converter in a 12-pin side-wettable TDFN package. All components are rated for the automotive temperature range. Various test points and jumpers are included for evaluation.

The standard EV kit comes with the MAX20077ATCA/VY+ installed (5V, 2.1MHz), but it can also be used to evaluate other MAX20077/MAX25277 variants with minimal component changes (e.g., IC replacement of U1).

Benefits and Features

- 3.5V to 36V Input Supply Range
- 5V or 3.3V Fixed Output Voltage, or Adjustable Between 1V and 10V
- Delivers Up to 2.5A Output Current
- Frequency-Synchronization Input
- Enable Input
- Voltage-Monitoring PGOOD Output
- Proven PCB Layout
- Fully Assembled and Tested

Quick Start

Required Equipment

- MAX20077 EV kit
- Power supply
- Voltmeter
- Electronic load

Procedure

The EV kit is fully assembled and tested. Follow the steps below to verify board operation:

- 1) Verify that all jumpers are in their default positions, as shown in Table 1.
- Connect the positive and negative terminals of the power supply to the SUP and GND test pads, respectively.
- 3) Connect the positive terminal of the voltmeter to OUT and the negative terminal to GND2.
- 4) Set the power supply to 14V and 2A current limit. Turn on the power supply.
- 5) With the PU and LED headers shorted, the green LED lights up. The voltmeter should display an output voltage of 5V.

Ordering Information appears at end of data sheet.



| JUMPER | SHUNT POSITION | FUNCTION |
|---------|----------------|--|
| EN | ON-Middle | Buck controller enabled |
| SPS | Middle-OFF | Spread spectrum disabled |
| PU, LED | Installed | PGOOD is pulled up by V_{BIAS} when OUT is in regulation |
| SYNC | Middle-FPWM | Forced-PWM mode |

Table 1. Default Jumper Settings

Detailed Description

The MAX20077 EV kit provides a proven layout for evaluating all variants of the MAX20077/MAX25277 family of small, current-mode-controlled buck converter ICs. Each device accepts input voltages as high as 36V and delivers up to 2.5A. The EV kit can handle an input-supply transient up to 40V.

Switching Frequency and External Synchronization

The ICs can operate in two modes, forced-PWM or skip. Skip mode has better efficiency for light-load conditions. When SYNC is pulled low, the device operates in skip mode for light loads, and in PWM mode for larger loads. When SYNC is pulled high, the device is forced to operate in PWM across all load conditions.

SYNC can be used to synchronize with other supplies if a clock source is present. The device is forced to operate in PWM when SYNC is connected to a clock source.

Buck Output Monitoring (PGOOD)

The EV kit provides a power-good output test point (PGOOD) to monitor the status of the buck output (OUT). PGOOD is low impedance when the output voltage is in regulation. PGOOD is high impedance when the output voltage drops below 8% (typ) of its nominal regulated voltage.

To obtain a logic signal, pull up PGOOD to $\mathsf{V}_{\mathsf{BIAS}}$ by installing shunts on jumpers PU and LED.

Evaluating Other Variants

The EV kit comes installed with the fixed-output, 5V/2.1MHz variant (MAX20077ATCA/VY+) The 2.1MHz and 400kHz

variants can be installed and tested with minimal component changes. For the 2.1MHz variants, install the appropriate IC on the EV kit (U1), while keeping all other components the same. For 400kHz parts, the inductor should be increased to 10µH, and the output capacitance must be a minimum 44µF after derating is accounted for. For MAX20077ATCE2 and MAX20077ATCD2 high-bandwidth parts, increase the output capacitance as per the guide-lines in the IC datasheet.

The MAX20077ATCC/VY+ can be installed for output voltages between 1V and 3V (2.1MHz). The inductor should be set to 4.7μ H, and the output capacitance must be a minimum 44μ F after derating is accounted for. The output voltage must be externally adjusted.

Setting the Output Voltage in the Buck Converters

To externally adjust the output voltage, remove R1 and install a 0Ω resistor on R4. Place appropriate resistors in positions R5 and R6 according to the following equation:

$$R5 = R6 \left[\left(\frac{V_{OUT}}{V_{FB}} \right) - 1 \right]$$

where $V_{FB} = 1V$ (typ) and R6 = 50k Ω .

Ordering Information

| PART | ТҮРЕ | | |
|----------------|--------------------------|--|--|
| MAX20077EVKIT# | 5V output, 2.1MHz EV kit | | |

#Denotes RoHS compliant.

Evaluates: MAX20077/MAX25277

| DESIGNATION | QTY | DESCRIPTION | |
|---------------|-----|---|--|
| C1 | 1 | 4.7uF ±10%, 50V X7R ceramic capacitors (1210) | |
| 61 | | TDK CGA6P3X7R1H475K250AB | |
| C2 | 1 | 47uF, 50V aluminum electrolytic capacitor (8.3mm x 8.3mm) | |
| 32 | | Panasonic EEE-FK1H470P | |
| C3, C4, C5 | 3 | 10uF ±10%, 25V X7R ceramic capacitor (1206) | |
| 00, 04, 00 | 0 | Taiyo Yuden TMJ316BB7106KLHT | |
| C7 | 1 | 1uF ±10%, 35V X7R ceramic capacitor (0603) | |
| 51 | • | TDK CGA3E1X7R1V105K080AC | |
| C8 | 1 | 0.1uF ±10% 50V X7R ceramic capacitor (0402) | |
| 66 | I | TDK CGA2B3X7R1H104K | |
| C10, C11 | 2 | 2.2uF ±10% 50V X7R ceramic capacitor (1210) | |
| 010, 011 | 2 | TDK CGA6M3X7R1H225K200AB | |
| DS1 | 1 | Green LED (0603) | |
| 531 | I | Lite-On Electronics LTST-C191KGKT | |
| EN, SPS, SYNC | 3 | 3-pin headers (0.1" spacing) | |
| L1 | 1 | 2.2μH Power Inductor | |
| L I | I | Coilcraft XFL5030-222 | |
| L2 | 1 | 2A Ferrite Bead (1210) | |
| LZ | I | Taiyo Yuden FBMH3225HM102NT | |
| PU, LED | 2 | 2-pin headers (0.1" spacing) | |
| R1, R2 | 2 | 0Ω resistor (0603) | |
| R3 | 1 | 3kΩ ±5% resistor (0603) | |
| U1 | 1 | Automotive Mini-Buck (12-pin SWTDFN) | |
| 01 | | Maxim MAX20077ATCA/VY+ | |
| _ | 5 | Shunt Jumper (0.1" spacing, Black) | |
| _ | 1 | PCB: MAX20077 Evaluation Kit | |

MAX20077 EV Kit Bill of Materials

MAX20077 EV Kit Schematic



Evaluates: MAX20077/MAX25277

MAX20077 Evaluation Kit www.maxim-ic.com 1-408-737-7600 maxim integrated. PGOOD R3 ■ 00 -00 DS1 SUPFILTER SUP C2 SYNC L1 C3 C4 C5 C6 BIAS GND O F B O F B R GND3 GND2 5 REV B CT 06-2017 Lead Free & RoHS Comp

MAX20077 EV Kit Component Placement Guide-Top



MAX20077 EV Kit PCB Layout-Internal Layer 2



MAX20077 EV Kit Component Placement Guide-Bottom



MAX20077 EV Kit PCB Layout–Internal Layer 3

MAX20077 EV PCB Layouts

Evaluates: MAX20077/MAX25277

Revision History

| REVISION NUMBER | REVISION DATE | DESCRIPTION | PAGES CHANGED |
|--------------------|------------------|--|------------------|
| 0 | 3/18 | Initial release | — |
| 1 | 12/18 | Added MAX25277 | 1–5 |
| 2 | 2/19 | Removed MAX25277 from references to EV kit title | 1–5 |

For pricing, delivery, and ordering information, please visit Maxim Integrated's online storefront at https://www.maximintegrated.com/en/storefront.html.

Maxim Integrated cannot assume responsibility for use of any circuitry other than circuitry entirely embodied in a Maxim Integrated product. No circuit patent licenses are implied. Maxim Integrated reserves the right to change the circuitry and specifications without notice at any time.